




**ATTENTION**  
 Turn off water supply and disconnect Rinse-o-matic from faucet after closing time. Periodically check water supply hose and connections for leakage.

## PRESSURE REGULATOR KIT

MANUFACTURED BY VITA-MIX® CORPORATION



This package contains one item #1439 which includes the following:


FIGURE	NAME	QTY.	ITEM NUMBER
1.	HOSE ASSEMBLY INLET (Female Connection)	1	1440
2.	WATER PRESSURE REGULATOR	1	---
3.	HOSE ASSEMBLY OUTLET (Male Connection)	1	1441
4.	INSTALLATION INSTRUCTIONS (Not Shown)	1	XRM010

Use the above item #s for ordering replacement parts.

### INSTALLATION INSTRUCTIONS

**PLEASE NOTE: This equipment is to be installed to comply with the applicable Federal, state, or local plumbing codes having jurisdiction.**

1. Ensure that you have received all of the parts in the diagram. If you are missing any parts, please contact the Vita-Mix Corporation at 800-437-4654 or 440-235-0214. If you live outside of the U.S., Canada or Latin America, contact your local Vita-Mix Distributor or telephone the Vita-Mix International Division at +1 440-782-2450.
2. Make sure that the faucet is turned off.
3. Remove the Rinse-o-matic® hose (Item 1) from the male quick disconnect insert (Item 2).
4. Unscrew the male quick disconnect (Item 2) from the Y-connector (Item 3) or from the faucet if the Y-connector is not being used.
5. Screw the female end of the pressure regulator assembly (Item 4) to the Y-connector (Item 3) or directly to the faucet if the Y-connector is not being used. (Make sure the rubber washer is inside the female end before tightening.)
6. Screw the male quick disconnect insert (Item 2) to the male end of the regulator assembly (Item 4).
7. Check all connections to ensure they are tight.
8. Reattach the Rinse-o-matic hose (Item 1) to the male quick disconnect insert (Item 2).
9. Turn on the cold water and use the Rinse-o-matic as intended.



### LIMITED ONE-YEAR WARRANTY

Vita-Mix® Corporation will repair or replace this product with new or rebuilt parts, free of charge, in the USA, Puerto Rico and Canada, in the event of a defect in materials or workmanship for a period of one year from the date of purchase. This warranty does not cover damage which occurs from shipment, accident, misuse, abuse, neglect, mishandling, misapplication, faulty installation, set-up adjustments, improper maintenance, alterations, modifications, tampering, negligence, lack of reasonable care, water power, acts of God, or repair or service by anyone other than a service facility authorized by Vita-Mix. Replacement nozzle parts, seals, suction cups, hoses and connectors are available for a reasonable cost. Vita-Mix Corporation shall not be liable for the loss of use of the product, inconvenience, loss or any other damages, whether direct, incidental, or consequential including, without limitation, damage to other equipment resulting from the use of this product, or arising out of any breach of this warranty.

This limited warranty is in lieu of any other warranty expressed or implied. No representative or any other person is authorized to make any other warranty or to assume liability not strictly in accordance with the foregoing. This limited warranty gives you specific legal rights which may vary from state to state. To obtain warranty service in the United States, Puerto Rico and Canada call the Vita-Mix Service Hot Line toll free at 800-437-4654, 440-235-0214 or write Vita-Mix Rinse-o-matic Service Center, 8615 Usher Rd., Cleveland, Ohio 44138-2103 USA. In order to receive warranty service you may be required to provide proof of purchase. Should it become necessary to transport your Rinse-o-matic Regulator Kit, make sure it is properly packaged to avoid damage. Transportation is the user's responsibility.



## **PRESSURE REGULATOR KIT**

**MANUFACTURED BY VITA-MIX® CORPORATION**

### **Instructions for external sanitizing of the Rinse-o-matic with Regulator Kit**

1. Make sure the water supply is off and disconnect the unit from the water supply.
2. Place the unit in a basin of warm (110° F / 43°C), clean water.
3. Add a mild dishwashing soap to the water according to the soap's recommended concentration.
4. Wash all surfaces with a soft cloth.
5. Wash hard to reach areas with a small, soft brush.

### **Instructions for internal sanitizing of the Rinse-o-matic with Regulator Kit**

1. Make sure the water supply is off and disconnect the regulator assembly from the water supply.
2. Relieve the residual water pressure in the unit by depressing the spray head plunger with a container.
3. Add a mild dishwashing soap to the female end of the regulator assembly to a 3/8" / 10 mm depth.
4. Taking care not to spill any dishwashing soap, reconnect the regulator assembly to the faucet.
5. If you are using the Y-connector, make sure that the valve controlling the flow to the Rinse-o-matic is on and the opposite valve is off. Turn the hot water supply on for approximately 5 seconds and shut it back off. This flushes the soap into the Rinse-o-matic unit.
6. Let the unit sit for a period of time determined by the soap manufacturer's recommendations. During this time, you can disconnect the unit from the faucet and put it aside, but do not depress either of the plungers as this would relieve the internal pressure. The internal pressure aids in cleaning.
7. Reconnect the unit to the faucet, and turn on the hot water supply.
8. Depress the sprayhead plunger for approximately 20 seconds to flush out the soap.
9. Repeat steps 1 through 9 at least two more times.

## **TROUBLESHOOTING**

### **A. The unit leaks at the hose connections.**

1. Screw the male quick disconnect insert to the regulator kit assembly tightly by hand. Be sure not to over-tighten.
2. Screw the female hose end of the regulator kit assembly tightly by hand. Make sure the rubber washer is inside the female end before tightening. Be sure not to over-tighten.
3. If the previous steps do not solve the problem, please contact Vita-Mix® Customer Service at **800-437-4654** or **440-235-0214**.\*

### **B. Water does not flow or the water pressure is very low.**

1. Ensure that the faucet is on.
2. Ensure that the valve on the leg of the Y-connector that supplies the Rinse-o-matic with water is on and that the valve on the opposite leg is off when attempting to use the Rinse-o-matic.
3. If the water supply line that supplies the Rinse-o-matic is used to supply water to any other equipment, make sure that equipment is not drawing water when attempting to use the Rinse-o-matic.
4. If the previous steps do not solve the problem, please contact Vita-Mix® Customer Service at **800-437-4654** or **440-235-0214**.\*

\*Outside the United States, Canada or Latin America contact your local Vita-Mix distributor or telephone the Vita-Mix International Division at +1 440-782-2450.